71056, In-Car Mounting Bracket for BMW 1 E81 - Vent

- With a flat bladed tool unclip the trim above the radio/CD
- Hook the upper bracket arm over the top of the vent assembly
- Locate the lower arm with the screw in the right of the recess adjacent to the 'Start' button
- Refit the trim

www.co-star.co.uk t: +44 (0) 1423 340066 e: sales@co-star.co.uk

Co-star will not be liable for any damage caused when fitting the bracket