

**CO:STAR\***

711128, In-Car Mounting Bracket for Mini 2007>



- Unclip the lower edge of the transmission tunnel side wall
- Slide fingers upwards to unclip: at the top pull the tip down and flex the rest of the panel out to release the top lug and clip
- Slide the panel downwards and out
- Locate the bracket with the central torx screw and refit the panel

**NB There is a strip of protective tape running vertically where the panel clips in place, this can be trimmed where the bracket arm crosses it**

[www.co-star.co.uk](http://www.co-star.co.uk)

t: +44 (0) 1423 340066

e: [sales@co-star.co.uk](mailto:sales@co-star.co.uk)

**Co-star will not be liable for any damage caused when fitting the bracket**