711159, In-Car Mounting Bracket for BMW X6

step 1: Remove the protective tape foil.

step 2: Insert the bracket arm between the fascia and console at the acc unit level.

step 3: Push home until the hooks grip behind the fascia and the tape adheres to the leading edge

www.co-star.co.uk t: +44 (0) 1423 340066 e: sales@co-star.co.uk

Co-star will not be liable for any damage caused when fitting the bracket