



711319, In-Car Mounting Bracket for Skoda Superb vent 2009>



Skoda Superb vent 2009>

Step 1: Unclip the moulding beneath the right central vent.

Step 2: Insert the upper arm of the bracket over the top of the vent assembly.

Step 3: Affix the lower arm of the bracket to the trim beneath the vent, with a self tapping screw.

Step 4: Refit the trim.

www.co-star.co.uk

t: +44 (0) 1423 340066

e: sales@co-star.co.uk

Co-star will not be liable for any damage caused when fitting the bracket