

CO STAR*

711299, In-Car Mounting Bracket for Ford Focus 2011-2014



- Insert the bracket between the ACC fascia and console edge
- Push home until the hooks grip behind the edge and the lip rests against the fascia
- Adhere the tape to the console edge

www.co-star.co.uk

t: +44 (0) 1423 340066

e: sales@co-star.co.uk

Co-star will not be liable for any damage caused when fitting the bracket