



Contactless reader

Reads available data from automotive CANbus and transmits it in original format to telematics unit



Basic solution for light commercial vehicles and personal cars





Insulation of wires without damage





Safe data reading through insulation of wires

- no influence on CAN bus operation
- power supply from onboard network
- easy installation and operation
- no preconfiguration needed
- compact and lightweight









Installation

- 1. Put CANCrocoLITE between CAN H and CAN L wires
- 2. Fix wires with plastic cable ties
- 3. Connect CANCrocoLITE to telematics unit and power supply